



EN

BRAINZ POWERBANK + SPEAKER BLACK INSTRUCTION MANUAL

PLEASE READ ALL INSTRUCTIONS CAREFULLY AND
RETAIN FOR FUTURE USE

This is what you need:

- USB Cable (included)
- USB Adapter or power supply (not included)
- AUX Cable (included, optional)
- Mobile device with Bluetooth



Product description:

3-in-1 power bank, speaker and built-in telephone stand. Equipped with a handy carrying handle to enjoy music everywhere. The strong power bank has the capacity to charge an average phone at least twice. Furthermore, it is equipped with an external AUX connection and SD card input.

This is how to charge it:

Plug one end of the USB cable into the power bank and the other end into the power supply. The power bank is now charging. You can see from the flashing lights on the side of the cable inputs how full the power bank is at the moment. The power bank is full when the lights stop flashing.

This is how you set it up:

Before turning on the speaker for the first time, make sure it is fully charged. To switch on the speaker, slide the button on the side to "On".

You can listen to music from the speaker in several ways:

- (1) Via Bluetooth: Switch on the Bluetooth of your phone or tablet. Then search for the speaker (BRAINZ Speaker P15) and pair your device with the speaker. The speaker is now ready to play music.
- (2) Via AUX cable: Plug one side of the AUX cable into your device and the other side into the speaker.
- (3) Via SD card: Put your favorite music on an SD card (not included) and place it in the speaker SD slot.

With the + and - button you can change to the previous and next song. Do you want to change the volume? Then press and hold the desired button for more than 2 seconds. You can also easily pause and resume the music with the pause button. Via the "M" button you can play music via the SD card. You can insert the SD card on the back of the speaker. The SD card is not included. Via the "+" and "-" button you can go to the next or previous song. These buttons can also be pressed for longer to increase and decrease the volume.

To charge your phone via the power bank, you can connect your phone to the power bank via the supplied USB cable. The power bank has enough power to fully charge your phone once.

You can extend the phone stand on the side of the powerbank. This allows you to easily put your phone on the speaker to watch a video and charge it at the same time via the supplied USB cable. Multifunctional!

This manual is applicable for item number 38533.

More information about this product is available on www.brainz-electronics.nl



NL

BRAINZ POWERBANK + SPEAKER ZWART

GEBRUIKSAANWIJZING

**GELIEVE DE INSTRUCTIES ZORGVULDIG TE LEZEN
EN TE BEWAREN VOOR LATER GEBRUIK**

Dit heeft u nodig:

- USB Kabel (inbegrepen)
- USB Adapter of voeding (niet inbegrepen)
- AUX Kabel (inbegrepen, optioneel)
- Mobiel apparaat met Bluetooth



Productomschrijving:

3-in-1 powerbank met speaker en ingebouwde telefoonstandaard. Voorzien van een handig draaghengsel om overal van muziek te kunnen genieten. De sterke powerbank heeft de capaciteit om een gemiddelde telefoon minimaal twee keer op te laden. Verder is deze voorzien van een externe AUX aansluiting en SD kaart input.

Zo laadt u het op:

Stop de ene kant van de USB-kabel in de powerbank, en de andere kant in de voeding. De powerbank laadt nu op. U kunt aan de knipperende lichten aan de kant van de kabel-ingangen zien hoe vol de powerbank op het moment is. De powerbank is vol als de lichten stoppen met knipperen.

Zo stelt u het in:

Voordat u de speaker voor de eerste keer aanzet moet u er eerst voor zorgen dat deze volledig is opgeladen. Om de speaker aan te zetten schuift u de knop op de zijkant naar 'On'.

U kunt op verschillende manieren muziek beluisteren vanuit de speaker:

- (1) Via bluetooth: Schakel de bluetooth van uw telefoon of tablet in. Zoek vervolgens naar de speaker (BRAINZ Speaker P15) en koppel uw apparaat met de speaker. De speaker is nu gereed om muziek af te spelen.
- (2) Via AUX kabel: Steek de ene kant van de AUX kabel in uw apparaat en de andere kant in de speaker.
- (3) Via SD kaart: Zet uw favoriete muziek op een SD kaart en plaats deze in de speaker.

Via de + en – knop kunt u naar het vorige en het volgende nummer veranderen. Wilt u het volume veranderen? Hou dan de gewenste knop langer dan 2 seconden ingedrukt. U kunt ook gemakkelijk de muziek pauzeren en hervatten met de pauze-knop. Via de 'M'-knop kunt u muziek afspelen via de SD-kaart. De SD-kaart kunt u aan de achterzijde van de speaker invoeren. De SD-kaart is niet meegeleverd. Via de '+' en '-' knop kunt u naar het volgende of vorige nummer gaan. Deze knoppen kunnen ook langer ingedrukt worden om het volume harder en zachter te zetten.

Om uw telefoon op laden via de powerbank, kunt u uw telefoon via de meegeleverde USB-kabel aan de powerbank koppelen. De powerbank heeft genoeg vermogen om uw telefoon eenmaal volledig op te laden.

Aan de zijkant kunt u de telefoonstandaard uitschuiven. Hierdoor kunt u gemakkelijk uw telefoon op de speaker zetten en tegelijkertijd een film kijken en de telefoon opladen via de meegeleverde USB-kabel. Multifunctioneel!

Deze handleiding is van toepassing op artikelnummer 38533.

Meer informatie over dit product vindt u op www.brainz-electronics.nl