



EN

BRAINZ LED KARAOKE MICROPHONE INSTRUCTION MANUAL

PLEASE READ THE INSTRUCTION CAREFULLY
AND KEEP THEM FOR FUTURE REFERENCE



What you need

- AUX Kabel (inbegrepen)
- DC5V/USB Kabel (inbegrepen)
- TF/SD Kaart (optioneel, niet inbegrepen)

How to charge the LED Karaoke Microphone

Insert the provided DC5V cable into the LED Karaoke Microphone and connect the USB end to a power source. When the red light is on, the microphone is charging.

How to set up the device

Press and hold the power button on the top of the microphone for 3 seconds. When you want to use a Bluetooth connection, open the Bluetooth menu on your device and search for 'BRAINZ S120.' Click on it to connect your phone, and the microphone is ready to use.

USB

You can play music via the USB port. Insert a USB flash drive into the designated access port.

TF/SD

You can play music with an SD card. Insert your SD card into the 'TF' port.

AUX

Insert the included AUX cable into the microphone input on your device and into the AUX input on the speaker. When the speaker is connected via AUX, Bluetooth turns off.

Volume

To adjust the microphone volume up or down, slide the 'mic vol' button up or down. This button is located at the bottom right of the control panel. Slide the button up to increase the microphone volume and down to decrease it.

Pause Music

Press the 'scan' button once to pause the music (▶||). Repeat this to resume the music.

Next/Previous Track

Press the 'prev' button to go to the previous track. Press 'next' to go to the next track.

LED Lighting

Click the 'rec' button to turn the LED lighting on or off. When the LED lighting is on, it responds to the music being played on the microphone.

Sound Remix

Slide the 'remix' button up to add an echo to the microphone.

Voice Changer

Hold the 'Rec' button for 3 seconds to set up the voice changer. With the voice changer, you can make your voice sound higher or lower.

Note:

Do not use a charger with a higher voltage than what is suitable for this product.

This manual is valid for article number 38598.
For more information about this product, please visit www.brainz-electronics.nl



NL

BRAINZ LED KARAOKE MICROFOON

GEBRUIKSAANWIJZING

GELIEVE DE INSTRUCTIES ZORGVULDIG TE LEZEN
EN TE BEWAREN VOOR LATER GEBRUIK



Dit heeft u nodig

- AUX Kabel (inbegrepen)
- DC5V/USB Kabel (inbegrepen)
- TF/SD Kaart (optioneel, niet inbegrepen)

Zo laadt u de LED Karaoke Microfoon op

Plaats de meegeleverde DC5V-Kabel in de LED Karaoke Microfoon en verbind de USB-zijde in een voedingsbron. Als de rode lamp brandt is de microfoon aan het opladen.

Zo stelt u het apparaat in

Houdt de aan/uit knop op de bovenzijde van de microfoon voor 3 seconden ingedrukt. Wanneer u gebruik wilt maken van een Bluetooth verbinding, opent u het Bluetooth-menu op uw apparaat en zoekt u naar 'BRAINZ S120'. Door hierop te klikken maakt uw telefoon verbinding en is de microfoon klaar voor gebruik.

USB

Via de USB-poort kunt u muziek afspelen. Plaats een USB-stick in de hiervoor bestemde toegangspoort.

TF/SD

Het is mogelijk om met een SD kaart muziek af te spelen. Plaats uw SD kaart in de 'TF'-poort.

AUX

Plaats de meegeleverde AUX Kabel in de microfooningang van uw apparaat en in de AUX ingang van de speaker. Wanneer de speaker via AUX verbonden is schakelt de Bluetooth uit.

Volume

Om het volume van de microfoon harder of zachter te zetten, schuift u het knopje 'mic vol' naar boven of naar beneden. Deze is rechts onderin te vinden op het bedieningspaneel. Schuif het knopje naar boven om de microfoon harder te zetten en naar beneden om de microfoon zachter te zetten.

Muziek pauzeren

Druk 1 keer op de 'scan' knop om de muziek te pauzeren (▶||). Herhaal dit om de muziek te hervatten.

Volgend/vorig nummer

Druk op de 'prev' knop om naar het vorige nummer te gaan. Druk op 'next' om naar het volgende nummer te gaan.

Ledverlichting

Klik op het 'rec' knopje om de ledverlichting te aan of uit te zetten. Wanneer de ledverlichting aan staat reageert deze op de muziek die afgespeeld wordt op de microfoon.

Geluid remixen

Schuif het 'remix' knopje naar boven om een echo toe te voegen aan de microfoon.

Stemvormer

Houdt het knopje 'Rec' ingedrukt voor 3 seconde om de stemvormer in te stellen. Met de stemvormer kunt u uw stem hoger of lager laten klinken.

Let op: Gebruik geen oplader met een hoger voltage dan geschikt voor dit product.

Deze handleiding is van toepassing op artikelnummer 38598.
Meer informatie over dit product vindt u op www.brainz-electronics.nl