



EN

BRAINZ SOLAR SPEAKER NOX GREEN

INSTRUCTION MANUAL

PLEASE READ THE INSTRUCTIONS CAREFULLY
AND KEEP THEM FOR FUTURE REFERENCE



What you need

- USB-C Cable (included)
- USB Adapter or USB Power Supply (not included)
- Bluetooth-enabled mobile phone, tablet or laptop (not included)
- TF/SD Card, USB (optional, not included)

How to charge the speaker

1. Place the speaker in a sunny spot with the solar panel facing the sun and the speaker will charge.
2. Connect the supplied cable to the speaker and plug the USB side into a power source. The speaker charges when you see a red light on. When the speaker is fully charged, the lamp will stop lighting up.

How to set up the device

Make sure the speaker is fully charged before using it. Turn on the speaker by pressing and holding the power button for 3 seconds. The speaker will appear under new Bluetooth connections on your device as 'BRAINZ S135'. Clicking on this will connect your phone and the speaker will be ready to use. The speaker will let you know if your phone is connected by a sound.

Volume

To turn up the volume, press the + button. To decrease the volume, press the - button.

Pausing music

Briefly click the pause button to pause the music. Repeat to resume music.

Next/previous song

To go to the previous song, briefly click the - button. To go to the next song, briefly click the + button.

Switching modes

Briefly click the 'M' button to switch between Bluetooth, radio, USB or TF/SD.

Radio

Place the speaker where a signal can be received and slide out the antenna. Click the 'M' button until you get to radio mode. Press and hold the pause button to connect to a channel.

USB

The USB port allows you to play your own music. Insert a USB stick into the speaker's dedicated access port.

TF/SD

It is possible to play music using your own SD card. Insert your SD card into the 'TF' port.

Change LED illumination

Press and hold the 'M' button for 2 seconds to switch off LED lighting. Repeat to turn it on again.

Switch off

To turn the speaker off, flip the slider.
Phone holder

Caution:

Do not use a charger with a higher voltage than suitable for this product.



NL

BRAINZ SOLAR SPEAKER NOX GROEN

GEBRUIKSAANWIJZING

**GELIEVE DE INSTRUCTIES ZORGVULDIG TE LEZEN
EN TE BEWAREN VOOR LATER GEBRUIK**



Dit heeft u nodig

- USB-C Kabel (inbegrepen)
- USB Adapter of USB Voeding (niet inbegrepen)
- Mobiele telefoon, tablet of laptop met Bluetooth (niet inbegrepen)
- TF/SD Kaart, USB (optioneel, niet inbegrepen)

Zo laadt u de speaker op

1. Zet de speaker op een zonnige plek met het zonnepaneel naar de zon gericht en de speaker zal opladen.
2. Verbind de meegeleverde kabel aan de speaker en verbind de USB zijde in een voedingsbron. De speaker laadt op als u een rode lamp ziet branden. Wanneer de speaker volledig is opgeladen, stopt de lamp met branden.

Zo stelt u het apparaat in

Zorg ervoor dat de speaker volledig is opgeladen voordat u deze gebruikt. Zet de speaker aan door de aan/uit knop 3 seconde ingedrukt te houden. De speaker zal onder de nieuwe Bluetooth connecties op uw apparaat verschijnen als 'BRAINZ S135'. Door hierop te klikken maakt uw telefoon verbinding en is de speaker klaar voor gebruik. De speaker laat weten of uw telefoon is verbonden door middel van een geluid.

Volume

Om het volume harder te zetten drukt u de + knop in. Om het volume zachter te zetten drukt u de - knop in

Muziek pauzeren

Klik kort op de pauze knop om de muziek te pauzeren. Herhaal dit om de muziek te hervatten.

Volgend/vorig nummer

Om naar het vorige nummer te gaan klik u kort op de – knop. Om naar het volgende nummer te gaan klikt u kort op de + knop.

Wisselen van modus

Klik kort op de 'M' knop om te wisselen tussen Bluetooth, radio, USB of TF/SD.

Radio

Plaats de speaker op een plek staat waar een signaal ontvangen kan worden en schuif de antenne uit. Klik op de 'M' knop tot u op de radio modus komt. Houdt de pauze knop ingedrukt om verbinding te maken met een kanaal.

USB

Via de USB-poort kunt u uw eigen muziek afspelen. Plaats een USB-stick in de hiervoor bestemde toegangspoort van de speaker.

TF/SD

Het is mogelijk om met een eigen SD kaart muziek af te spelen. Plaats uw SD kaart in de 'TF'-poort.

LED verlichting wijzigen

Houd de 'M' knop 2 seconde ingedrukt om van LED verlichting uit zetten. Herhaal dit om deze weer aan te zetten.

Uitzetten

Om de speaker uit te zetten zet u het schuifknopje om.

Let op:

Gebruik geen oplader met een hoger voltage dan geschikt voor dit product.