



EN

BRAINZ FAST CHARGER POWERBANK DON INSTRUCTION MANUAL

PLEASE READ THE INSTRUCTIONS CAREFULLY
AND KEEP THEM FOR FUTURE REFERENCE



What you need

- USB-C Cable (included)
- USB Adapter or USB Power Supply (not included)
- Mobile device

Charging the powerbank

Fully charge the powerbank, using the included USB-C cable. When the powerbank is charging, the last digit of the battery percentage will flash. Once fully charged, the powerbank will indicate 100%.

Device charging

Make sure the powerbank is fully charged. The powerbank has 4 different outputs: micro-USB, USB-C, Lightning and USB. Connect the desired device to the powerbank by matching the appropriate output to the device.

Battery percentage

To see the battery percentage, briefly press the button on the side of the powerbank once. Repeat to turn it off again.

Flashlight

Press and hold the button on the side of the powerbank for 4 seconds to activate the torch. Repeat to turn it off again.

Caution:

Do not use a charger with a higher voltage than suitable for this product.



NL

BRAINZ FAST CHARGER POWERBANK DON GEBRUIKSAANWIJZING

GELIEVE DE INSTRUCTIES ZORGVULDIG TE LEZEN
EN TE BEWAREN VOOR LATER GEBRUIK



Dit heeft u nodig

- USB-C Kabel (inbegrepen)
- USB Adapter of USB Voeding (niet inbegrepen)
- Mobiel apparaat

Powerbank opladen

Laad de powerbank volledig op, door middel van de bijgeleverde USB-C kabel. Wanneer de powerbank aan het opladen is zal het laatste cijfer van de batterijpercentage gaan knipperen. Zodra de powerbank volledig is opgeladen zal deze 100% aangeven.

Apparaat opladen

Zorg ervoor dat de powerbank volledig opgeladen is. De powerbank heeft 4 verschillende outputs: micro USB, USB-C, Lightning en USB. Sluit het gewenste apparaat aan op de powerbank door de passende output te koppelen aan het apparaat.

Batterijpercentage

Om de batterijpercentage te zien drukt u één keer kort op de knop aan de zijkant van de powerbank. Herhaal dit om deze weer uit te zetten.

Zaklamp

Houd de knop aan de zijkant van de powerbank 4 seconde ingedrukt om de zaklamp te activeren. Herhaal dit om deze weer uit te zetten.

Let op:

Gebruik geen oplader met een hoger voltage dan geschikt voor dit product.