



EN

BRAINZ TUBE SPEAKER INSTRUCTION MANUAL

PLEASE READ ALL INSTRUCTIONS CAREFULLY AND
RETAIN FOR FUTURE USE

This is what you need:

- USB Cable (included)
- SD Card (not included, optional)
- Mobile phone or other device with Bluetooth



Product description:

Small Bluetooth speaker with rechargeable battery. Also equipped with an SD port for playing MP3 files. The speaker has an elegant rubber finish. As an extra, the music can also be operated on the speaker itself.

This is how to charge it:

Connect the USB cable to the speaker and then connect it to a power supply. When you have done this, a red lamp on the speaker will light up. This means that the speaker is charging. The speaker is fully charged when the light on the speaker goes out.

This is how you set it up:

Put the speaker in the mode you want to use. You can use the speaker in 2 ways. You can pair the speaker by using the Bluetooth function. You can also use an SD card with MP3 songs on it.

If you are going to use the Bluetooth function, slide the button on the side of the speaker to the Bluetooth logo. The light on the speaker will now flash blue. Now you can search for the speaker on your phone. Click on the speaker in the Bluetooth menu on your phone. The phone will now pair with the speaker. The speaker is paired when the speaker indicates this.

To use the MP3 function, you need an SD card (not included). You will first have to put MP3 music files on your SD card. Ready? Then insert the SD card into the appropriate port on the speaker. Now set the slider to MP3. The speaker will now start playing your music from the card.

You can change tracks by using the back and forward buttons. Press and hold the back button for 2 seconds to decrease the volume. Press and hold the forward button for 2 seconds to increase the volume.

You can switch off the speaker by setting the slider in the middle to "Off".

This manual is applicable for item number 38522.

More information about this product is available on www.brainz-electronics.nl



NL

BRAINZ TUBE SPEAKER GEBRUIKSAANWIJZING

GELIEVE DE INSTRUCTIES ZORGVULDIG TE LEZEN
EN TE BEWAREN VOOR LATER GEBRUIK

Dit heeft u nodig:

- USB Kabel (inbegrepen)
- SD-kaart (niet inbegrepen, optioneel)
- Mobiele telefoon of ander apparaat met Bluetooth



Productomschrijving:

Kleine Bluetooth speaker met oplaadbare batterij. Ook voorzien van een SD poort voor het afspelen van MP3 bestanden. De speaker heeft een elegante rubberen afwerking. Als extra is de muziek ook bedienbaar op de speaker zelf.

Zo laadt u het op:

Sluit de USB-kabel aan de speaker en verbind het andere uiteinde van de kabel vervolgens aan een voeding. Als u dit gedaan heeft begint er een rode lamp op de speaker te branden. Dit betekent dat de speaker aan het opladen is. De speaker is volledig opgeladen op het moment dat het licht op de speaker uitgaat.

Zo stelt u het in:

Zet de speaker in de modus die u wilt gebruiken. U kunt de speaker op 2 manieren gebruiken. U kunt de speaker koppelen door de Bluetooth-functie te gebruiken. Ook kunt u gebruik maken van een SD-kaart met MP3-muziek erop.

Als u gebruik gaat maken van de Bluetooth-functie, schuif de knop op de zijkant van de speaker dan naar het Bluetooth-logo. Het licht op de speaker knippert nu blauw. Nu kunt u op uw telefoon de speaker zoeken. Klik op de speaker in het Bluetooth-menu op uw telefoon. De telefoon gaat nu koppelen met de speaker. De speaker is gekoppeld als de speaker dit aangeeft.

Als u gebruikt wilt maken van de MP3-functie, heeft u een SD-kaart nodig (niet meegeleverd). Hier zult u eerst MP3 muziek op moeten zetten. Gereed? Stop dan de SD-kaart in de daarvoor bestemde poort van de speaker. Zet nu de schuif-knop op MP3. De speaker begint nu met uw muziek afspelen.

Door de terug -en vooruitknop te gebruiken kunt u van nummer wisselen. Houd de terug-knop 2 seconden ingedrukt om het volume zachter te zetten. Houd de vooruit-knop 2 seconden ingedrukt om het volume harder te zetten.

U kunt de speaker uitzetten door de schuif-knop in het midden op 'Off' te zetten.

Deze handleiding is van toepassing op artikelnummer 38522.

Meer informatie over dit product vindt u op www.brainz-electronics.nl