



EN

BRAINZ POWER CUBE SPEAKER INSTRUCTION MANUAL

PLEASE READ THE INSTRUCTIONS CAREFULLY
AND KEEP THEM FOR FUTURE REFERENCE



What you need

- USB-C cable (included)
- Mobile phone with Bluetooth (not included)

How to charge the Powercube Speaker

Connect the supplied USB-C cable to the back of the speaker and connect the USB side to a power source. The speaker will now charge.

Switching on

Slide the ON/OFF button up on the back of the speaker to turn it on. The speaker will appear under your new Bluetooth connections on your phone as Brainz Speaker S45. By clicking on it, your phone will connect and the speaker is ready for use.

Volume

To increase volume, press and hold the + button.

To decrease volume, press and hold the - button.

Next/previous song

To select the next song, press the + button.

To select the previous number, repeat for the button with the - button.

AUX

To use the AUX port, plug one end of your AUX cable into your phone and the other end into the AUX port of the speaker. Now the speaker will automatically switch to AUX and disable Bluetooth. The AUX port is found on the back of the speaker.

SD

Thanks to the SD access port, you can play MP3 files. To do this, insert an SD card into the access port. This access port is also found on the back of the speaker.

Switching off

Slide the ON/OFF button down on the back of the speaker to turn it off.

Please note:

Do not use a charger with a higher voltage than suitable for this product.

Please note:

This product is not dishwasher safe. Clean item with a damp cloth.



NL

BRAINZ POWER CUBE SPEAKER GEBRUIKSAANWIJZING

GELIEVE DE INSTRUCTIES ZORGVULDIG TE LEZEN
EN TE BEWAREN VOOR LATER GEBRUIK



Dit heeft u nodig

- USB-C kabel (inbegrepen)
- Mobiele telefoon met Bluetooth (niet inbegrepen)

Zo laadt u de draadloze oplaad speaker op

Verbind de meegeleverde USB-C kabel aan de speaker (achterkant) en verbind de USB-zijde aan een voedingsbron. De speaker laadt nu op.

Zo stelt u het in

Schuif de ON/OFF knop naar boven op de achterkant van de speaker om deze aan te zetten. De speaker zal onder uw nieuwe Bluetooth connecties op uw telefoon verschijnen als Brainz Speaker S45. Door hierop te klikken maakt uw telefoon verbinding en is de speaker klaar voor gebruik.

Volume

Om het volume harder te zetten, houdt u de + knop ingedrukt.

Om volume zachter te zetten, houdt u de - knop ingedrukt.

Volgende/ vorige nummer

Om het volgende nummer te selecteren, drukt u op de + knop.

Om het vorige nummer te selecteren, herhaalt u dit voor de knop met het – teken.

AUX

Als u gebruik wilt maken van de AUX poort stopt u het ene eind van uw AUX kabel in uw telefoon en het andere eind in de 'AUX-poort van de speaker. Nu zal de speaker automatisch overgaan op AUX en schakelt hij de Bluetooth uit. De AUX toegangspoort is te vinden aan de achterkant van de speaker onder de ON/OFF knop.

SD

Dankzij de SD toegangspoort kunt u MP3-bestanden afspelen. Stop hiervoor een SD-kaart in de toegangspoort. Ook deze toegangspoort is te vinden aan de achterkant van de speaker.

Uitzetten

Schuif de ON/OFF knop naar onder op de achterkant van de speaker om deze uit te zetten.

Let op:

Gebruik geen oplader met een hoger voltage dan geschikt voor dit product.

Let op:

Dit artikel is niet vaatwasser bestendig. Maak schoon met een nat doekje.