



EN

BRAINZ POWERBAR SPEAKER INSTRUCTION MANUAL

PLEASE READ THE INSTRUCTIONS CAREFULLY
AND KEEP THEM FOR FUTURE REFERENCE



What you need

- USB-C cable (included)
- Mobile phone with Bluetooth (not included)

How to charge the Powerbar speaker

Connect the supplied cable to the speaker (DC5V port on the back of the speaker) and connect the USB side to a power source. The speaker will now charge.

This is how to set it up

Slide the ON/OFF button to the right on the back of the speaker to turn it on. The speaker will appear under your new Bluetooth connections on your phone as Brainz Speaker S65. By clicking on it, your phone connects and the speaker is ready for use.

Volume

To increase the volume, press and hold the + button on the top of the speaker. To decrease the volume, repeat with the - button.

Pause music

Press the pause button once to pause the music (button with triangle/ 2 dashes). Repeat to resume music.

Next/ previous song

Press the + button once to go to the next track. Repeat with the - button to go to the previous track.

AUX

To use the AUX port, plug one end of your AUX cable into your phone and the other end into the speakers AUX port. The speaker will now automatically switch to AUX and disable Bluetooth. The AUX port is found on the back of the speaker under the ON/OFF button.

USB

Thanks to the USB access port, you can play MP3 files. To do this, insert a USB into the access port. This access port is also found on the back of the speaker.

SD

Thanks to the SD access port, you can play MP3 files. To do this, insert an SD card into the access port. This access port is also found on the back of the speaker.

Switch off

Slide the switch button on the back of the speaker to the left to turn it off.

Please note:

Do not use a charger with a higher voltage than suitable for this product.

Please note:

This item is not dishwasher safe. Clean with a wet cloth.



NL

BRAINZ POWERBAR SPEAKER

GEBRUIKSAANWIJZING

GELIEVE DE INSTRUCTIES ZORGVULDIG TE LEZEN
EN TE BEWAREN VOOR LATER GEBRUIK



Dit heeft u nodig

- USB-C kabel (inbegrepen)
- Mobiele telefoon met Bluetooth (niet inbegrepen)

Zo laadt u de Powerbar speaker op

Verbind de meegeleverde kabel aan de speaker (DC5V-poort aan de achterzijde van de speaker) en verbind de USB-zijde aan een voedingsbron. De speaker laadt nu op.

Zo stelt u het in

Schuif de ON/OFF knop naar rechts op de achterkant van de speaker om deze aan te zetten. De speaker zal onder uw nieuwe Bluetooth connecties op uw telefoon verschijnen als Brainz Speaker S65. Door hierop te klikken maakt uw telefoon verbinding en is de speaker klaar voor gebruik.

Volume

Om het volume harder te zetten houdt u de + knop aan de bovenzijde van de speaker ingedrukt. Om het volume zachter te zetten herhaalt u dit met de – knop.

Muziek pauzeren

Druk 1 keer op de pauze knop om de muziek te pauzeren (knop met driehoek/ 2 streepjes). Herhaal dit om de muziek te hervatten.

Volgende/vorige nummer

Druk eenmalig op de + knop om naar het volgende nummer te gaan. Herhaal dit met de – knop om naar het vorige nummer te gaan.

AUX

Als u gebruik wilt maken van de AUX poort stopt u het ene eind van uw AUX kabel in uw telefoon en het andere eind in de 'AUX-poort van de speaker. Nu zal de speaker automatisch overgaan op AUX en schakelt hij de Bluetooth uit. De AUX toegangspoort is te vinden aan de achterkant van de speaker onder de ON/OFF knop.

USB

Dankzij de USB toegangspoort kunt u MP3-bestanden afspelen. Stop hiervoor een USB in de toegangspoort. Ook deze toegangspoort is te vinden aan de achterkant van de speaker.

SD

Dankzij de SD toegangspoort kunt u MP3-bestanden afspelen. Stop hiervoor een SD-kaart in de toegangspoort. Ook deze toegangspoort is te vinden aan de achterkant van de speaker.

Uitzetten

Schuif de switch knop aan de achterzijde van de speaker naar links om deze uit te zetten.

Let op:

Gebruik geen oplader met een hoger voltage dan geschikt voor dit product.

Let op:

Dit artikel is niet vaatwasser bestendig. Maak schoon met een nat doekje.

Deze handleiding is van toepassing op artikelnummer 38572 & 38573.
Meer informatie over dit product vindt u op www.brainz-electronics.nl