



EN

BRAINZ RYTHM SPEAKER WHEATSTRAW INSTRUCTION MANUAL

PLEASE READ THE INSTRUCTIONS CAREFULLY
AND KEEP THEM FOR FUTURE REFERENCE

What you need

- DC5V/USB Cable (included)
- Mobile phone, tablet, or laptop with Bluetooth (not included)



How to charge the Rhythm speaker

Connect the provided cable to the speaker and plug the USB end into a power source. Once you've done this, a red light will start glowing. This indicates that the speaker is charging. The speaker is fully charged when the light under the speaker goes out.

How to set up the device

You turn on the speaker by holding the 'On/Off' button for three seconds. The speaker will appear among the new Bluetooth connections on your device as BRAINZ Speaker S35. Click on it to connect your device, and the speaker is ready for use.

Volume

To increase the volume, press and hold the + button on the bottom of the speaker. To decrease the volume, press and hold the - button.

Pause music

Press the pause button once to pause the music (▶||). Repeat this to resume the music.

Incoming call

If you receive a call while connected to the speaker, press the 'Phone' button beneath the speaker to answer the call.

Hang up

To hang up, press the 'Phone' button for a few seconds.

Turning off

You can turn off the speaker by holding the 'On/Off' button for three seconds.

Phone holder

The speaker also functions as a phone holder. Simply place your phone on top of the speaker.

Note:

Do not use a charger with a higher voltage than what is suitable for this product.



NL

BRAINZ RYTHM SPEAKER TARWESTRO

GEbruIKSAANWIJZING

**GELIEVE DE INSTRUCTIES ZORGVULDIG TE LEZEN
EN TE BEWAREN VOOR LATER GEBRUIK**

Dit heeft u nodig

- DC5V Kabel / USB Kabel (inbegrepen)
- USB-Adapter (niet inbegrepen)
- Mobiele telefoon, tablet of laptop met Bluetooth (niet inbegrepen)



Zo laadt u de tarwestro Rythm speaker op

Verbind de meegeleverde kabel aan de speaker en verbind de USB-zijde aan een voedingsbron. Als u dit gedaan heeft begint er een rode lamp te branden. Dit betekent dat de speaker aan het opladen is. De speaker is volledig opgeladen op het moment dat het licht onder de speaker uitgaat.

Zo stelt u het apparaat in

U zet de speaker aan door de 'aan/uit'-knop drie seconde ingedrukt te houden. De speaker zal onder de nieuwe Bluetooth connecties op uw apparaat verschijnen als BRAINZ Speaker S35. Door hierop te klikken maakt uw apparaat verbinding en is de speaker klaar voor gebruik.

Volume

Om het volume harder te zetten houdt u de + knop aan de onderkant van de speaker ingedrukt. Om het volume zachter te zetten houdt u de - knop ingedrukt.

Muziek pauzeren

Druk 1 keer op de pauze knop om de muziek te pauzeren (▶||). Herhaal dit om de muziek te hervatten.

Inkomende oproep

Als u gebeld wordt terwijl u verbonden bent met de speaker drukt u op de 'Telefoon'-knop onder de speaker en zal deze uw oproep beantwoorden.

Ophangen

Als u wilt ophangen drukt u de 'Telefoon'-knop voor een aantal seconden in.

Uitzetten

U kunt de speaker uitzetten door de 'aan/uit'-knop drie seconde ingedrukt te houden.

Telefoonhouder

De speaker dient ook als telefoonhouder. Zet hiervoor uw telefoon in de bovenkant van de speaker.

Let op:

Gebruik geen oplader met een hoger voltage dan geschikt voor dit product.