



EN

BRAINZ POWERBAR SPEAKER WHEATSTRAW INSTRUCTION MANUAL

PLEASE READ THE INSTRUCTIONS CAREFULLY
AND KEEP THEM FOR FUTURE REFERENCE

What you need

- DC5V/USB Cable (included)
- Mobile phone, tablet, or laptop with Bluetooth (not included)
- TF/SD Card (optional, not included)



How to charge the Powerbar Speaker

Connect the DC5V cable to the Powerbar speaker and plug the USB end into a power source.

How to set up the device

Slide the ON/OFF switch to the left on the back of the speaker to turn it on. The speaker will appear among your new Bluetooth connections on your phone as BRAINZ Speaker S130. Click on it to connect your phone, and the speaker is ready for use.

Volume

To increase the volume, press and hold the + button on the top of the speaker. To decrease the volume, press and hold the - button.

Pause music

Press the pause button once to pause the music (▶||). Repeat this to resume the music.

Next/previous song

Press the + button once to go to the next track. Press the - button once to go to the previous track.

AUX

Insert the provided AUX cable into the microphone input of your device and into the AUX input of the speaker. When the speaker is connected via AUX, it will turn off Bluetooth.

USB

With the USB access port, you can play MP3 files. Insert a USB drive into the access port.

TF/SD

It is possible to play music with your own SD card. Insert your SD card into the 'TF' port.

LED lighting

Click on the 'light' icon to change the color of the LED lighting.

Switching between modes

Click on the 'M' button at the back of the device to switch between Bluetooth, USB, and SD/TF.

Turning off

Slide the switch button on the back of the speaker to the right to turn it off.

Phone holder

The speaker also serves as a phone holder. Place your phone on top of the speaker.

Note:

Do not use a charger with a higher voltage than what is suitable for this product.

This manual is valid for article number 38613.
For more information about this product, please visit www.brainz-electronics.nl



NL

BRAINZ POWERBAR SPEAKER TARWESTRO

GEBRUIKSAANWIJZING

**GELIEVE DE INSTRUCTIES ZORGVULDIG TE LEZEN
EN TE BEWAREN VOOR LATER GEBRUIK**

Dit heeft u nodig

- DC5V/USB Kabel (inbegrepen)
- Mobiele telefoon, tablet of laptop met Bluetooth (niet inbegrepen)
- TF/SD Kaart (optioneel, niet inbegrepen)



Zo laadt u de Tarwestro Powerbar Speaker op

Verbind de DC5V-Kabel aan de Powerbar speaker en verbind de USB-zijde in een voedingsbron.

Zo stelt u het apparaat in

Schuif de ON/OFF knop naar links op de achterkant van de speaker om deze aan te zetten. De speaker zal onder uw nieuwe Bluetooth connecties op uw telefoon verschijnen als BRAINZ Speaker S130. Door hierop te klikken maakt uw telefoon verbinding en is de speaker klaar voor gebruik.

Volume

Om het volume harder te zetten houdt u de + knop op de bovenzijde van de speaker ingedrukt. Om het volume zachter te zetten houdt u de - knop ingedrukt.

Muziek pauzeren

Druk 1 keer op de pauze knop om de muziek te pauzeren (▶||). Herhaal dit om de muziek te hervatten.

Volgend/vorig nummer

Druk eenmalig op de + knop om naar het volgende nummer te gaan. Druk eenmalig op de – knop om naar het vorige nummer te gaan.

AUX

Plaats de meegeleverde AUX Kabel in de microfooningang van uw apparaat en in de AUX ingang van de speaker. Wanneer de speaker via AUX verbonden schakelt hij de Bluetooth uit.

USB

Dankzij de USB toegangspoort kunt u MP3-bestanden afspelen. Plaats hiervoor een USB in de toegangspoort.

TF/SD

Het is mogelijk om met een eigen SD kaart muziek af te spelen. Plaats uw SD kaart in de 'TF'-poort.

Ledverlichting

Klik op het 'licht' icoon om de kleur van de ledverlichting te wijzigen.

Wisselen van modes

Klik op de 'M'-knop aan de achterkant van het apparaat om van te wisselen tussen Bluetooth, USB en SD/TF.

Uitzetten

Schuif de switch knop aan de achterzijde van de speaker naar rechts om deze uit te zetten.

Telefoonhouder

De speaker dient ook als telefoonhouder. Zet hiervoor uw telefoon in de bovenkant van de speaker.

Let op:

Gebruik geen oplader met een hoger voltage dan geschikt voor dit product.

Deze handleiding is van toepassing op artikelnummer 38613.
Meer informatie over dit product vindt u op www.brainz-electronics.nl