



**EN**

# **BRAINZ POWERBANK 5000MAH BLACK INSTRUCTION MANUAL**

**PLEASE READ THE INSTRUCTIONS CAREFULLY  
AND KEEP THEM FOR FUTURE REFERENCE**



## **What you need**

- USB-C Cable (included)
- USB Adapter or USB Power Supply (not included)
- Bluetooth mobile phone or tablet (not included)

## **Charging the powerbank**

First, fully charge the powerbank with the included USB-C cable and a power source (not included). When the powerbank is charging, the four blue lights will flash. The powerbank is fully charged when the lights stop flashing.

## **Charging your device**

You charge your phone or tablet by connecting the supplied cable to your device and the powerbank. In some devices this cable does not fit, use your own. The cable can be connected to the bottom of the powerbank. The powerbank turns on automatically as soon as the cable is paired.

## **Battery percentage**

To see the powerbank's battery percentage, briefly press the button on the side of the powerbank once. When four lights appear, the powerbank is completely full. When one light appears, the powerbank is almost empty. Repeat to turn the lights off again.

## **Caution:**

**Do not use a charger with a higher voltage than suitable for this product.**



NL

## BRAINZ POWERBANK 5000MAH ZWART GEBRUIKSAANWIJZING

GELIEVE DE INSTRUCTIES ZORGVULDIG TE LEZEN  
EN TE BEWAREN VOOR LATER GEBRUIK



### Dit heeft u nodig

- USB-C Kabel (inbegrepen)
- USB Adapter of USB Voeding (niet inbegrepen)
- Mobiele telefoon of tablet Bluetooth (niet inbegrepen)

### Powerbank opladen

Laad de powerbank eerst volledig op met de bijgeleverde USB-C kabel en een voedingsbron (niet ingegrepen). Wanneer de powerbank aan het opladen is gaan de vier blauwe lampje knipperen. De powerbank is volledig opgeladen als de lichten stoppen met knipperen.

### Apparaat opladen

U laadt uw telefoon of tablet op door de meegeleverde kabel op uw device en de powerbank aan te sluiten. In sommige apparaten past deze kabel niet, gebruik dan uw eigen kabel. De kabel kan aan de onderzijde van de powerbank gekoppeld worden. De powerbank gaat automatisch aan zodra de kabel gekoppeld wordt.

### Batterijpercentage

Om het batterijpercentage van de powerbank te zien drukt u één keer kort op de knop aan de zijkant van de powerbank. Wanneer de vier lampjes verschijnen is de powerbank helemaal vol. Bij één lampje is de powerbank bijna leeg. Herhaal dit om de lampjes weer uit te zetten.

### Let op:

Gebruik geen oplader met een hoger voltage dan geschikt voor dit product.