



EN

BRAINZ SPEAKER DEX BLACK

INSTRUCTION MANUAL

PLEASE READ THE INSTRUCTIONS CAREFULLY
AND KEEP THEM FOR FUTURE REFERENCE



What you need

- USB-C Cable (included)
- Mobile device with Bluetooth
- TF/SD Card, USB (optional, not included)

How to charge the speaker

Connect the supplied cable to the speaker and plug the USB side into a power source. The speaker is charging when you see a red light on. When the speaker is fully charged, the red light will turn off.

How to set up the device

Make sure the speaker is fully charged before using it. Turn on the speaker by pressing and holding the power button for 3 seconds. The speaker will appear under the new Bluetooth connections on your device as 'BRAINZ S145'. Clicking on this will connect your device and the speaker will be ready to use. The speaker will let you know if your device is connected by a sound.

Volume

Press and hold the + button to increase the volume. To turn down the volume, press and hold the - button. When the speaker has reached maximum volume, this is indicated by a sound.

Pausing music

Briefly click the power button to pause the music. Repeat to resume music.

Next/previous number

To go to the previous number, briefly click the - button. To go to the next song, briefly click the + button.

Switching modes

Briefly click the M button to switch between Bluetooth, USB or TF/SD.

USB

The USB port allows you to play your own music. Insert a USB stick into the speaker's dedicated access port.

TF/SD

It is possible to play music using your own SD card. Insert your SD card into the 'TF' port.

Change LED illumination

Press and hold the M button for 2 seconds to change LED illumination. Repeat this step several times to switch off the LED illumination.

Turn off

Press and hold the power button for 3 seconds to switch off the speaker.

Caution:

Do not use a charger with a higher voltage than suitable for this product.



NL

BRAINZ SPEAKER DEX ZWART GEBRUIKSAANWIJZING

GELIEVE DE INSTRUCTIES ZORGVULDIG TE LEZEN
EN TE BEWAREN VOOR LATER GEBRUIK



Dit heeft u nodig

- USB-C Kabel (inbegrepen)
- USB Adapter of USB Voeding (niet inbegrepen)
- Mobiele telefoon, tablet of laptop met Bluetooth (niet inbegrepen)
- TF/SD Kaart, USB (optioneel, niet inbegrepen)

Zo laadt u de speaker op

Verbind de meegeleverde kabel aan de speaker en verbind de USB zijde in een voedingsbron. De speaker laadt op als u een rood lampje ziet branden. Wanneer de speaker volledig is opgeladen, zal het rode lampje uitgaan.

Zo stelt u het apparaat in

Zorg ervoor dat de speaker volledig is opgeladen voordat u deze gebruikt. Zet de speaker aan door de aan/uit knop 3 seconde ingedrukt te houden. De speaker zal onder de nieuwe Bluetooth connecties op uw apparaat verschijnen als 'BRAINZ S145'. Door hierop te klikken maakt uw apparaat verbinding en is de speaker klaar voor gebruik. De speaker laat weten of uw apparaat verbonden is door middel van een geluid.

Volume

Houd de + knop ingedrukt om het volume te verhogen. Om het volume zachter te zetten houdt u de – knop ingedrukt. Wanneer de speaker de maximale volume heeft bereikt wordt dit aangegeven met een geluid

Muziek pauzeren

Klik kort op de aan/uit knop om de muziek te pauzeren. Herhaal dit om de muziek te hervatten.

Volgend/vorig nummer

Om naar het vorige nummer te gaan klik u kort op de – knop. Om naar het volgende nummer te gaan klikt u kort op de + knop.

Wisselen van modus

Klik kort op de M knop om te wisselen tussen Bluetooth, USB of TF/SD.

USB

Via de USB-poort kunt u uw eigen muziek afspelen. Plaats een USB-stick in de hiervoor bestemde toegangspoort van de speaker.

TF/SD

Het is mogelijk om met een eigen SD kaart muziek af te spelen. Plaats uw SD kaart in de 'TF'-poort.

LED verlichting wijzigen

Houd de M knop 2 seconde ingedrukt om van LED verlichting te wijzigen. Herhaal deze stap meerdere keren om de LED verlichting uit te zetten.

Uitzetten

Houd de aan/uit knop 3 seconde ingedrukt om de speaker uit te schakelen.

Let op:

Gebruik geen oplader met een hoger voltage dan geschikt voor dit product.