



EN

BRAINZ LANTERN JILL BLACK INSTRUCTION MANUAL

PLEASE READ THE INSTRUCTIONS CAREFULLY
AND KEEP THEM FOR FUTURE REFERENCE



What you need

- USB-C Cable (included)
- Bluetooth-enabled mobile device

How to charge the lantern

Connect the included cable to the lantern and connect the USB side to a power source. The lantern's light will come on. Once the lantern is fully charged, the light will turn off. If you don't want the light on while charging, press and hold the light icon for 3 seconds.

How to set it up

Make sure the lantern is fully charged before using it. Turn on the speaker by pressing and holding the 'O' button for 3 seconds. The speaker will appear under the new Bluetooth connections on your device as 'BRAINZ S165'. Clicking on this will connect your phone and the speaker will be ready to use. The speaker will let you know if your phone is connected by a sound.

Volume

Briefly click the + button to increase the volume. To turn the volume down, click the - button.

Pause music

Briefly click the 'O' button to pause the music. Repeat to resume music.

Switching the light on/off

Press and hold the light icon for 3 seconds to turn the lamp on. Repeat to turn the lamp off.

Adjusting brightness

Click 2x in quick succession on the light icon to adjust the brightness of the light. The lantern has 3 settings.

Pairing lanterns

If you have two Lantern Speakers, you can pair them for an even better sound experience. Switch on both speakers, do not yet connect them to bluetooth and place them next to each other. At one of the speakers, double-click the + button. The lights on both speakers will flash when the speakers are connected. Note this may take a few seconds. Connect the speaker set with bluetooth. The lights will stop flashing. Once connected, the speakers will remain connected.

Turn off

Press and hold the power button for 3 seconds to turn off the speaker.

Caution:

Do not use a charger with a higher voltage than suitable for this product.



NL

BRAINZ LANTAARN SPEAKER JILL ZWART GEBRUIKSAANWIJZING

GELIEVE DE INSTRUCTIES ZORGVULDIG TE LEZEN
EN TE BEWAREN VOOR LATER GEBRUIK



Dit heeft u nodig

- USB-C Kabel (inbegrepen)
- Mobiel apparaat met Bluetooth

Zo laadt u de lantaarn op

Verbind de meegeleverde kabel aan de lantaarn en verbind de USB zijde aan een voedingsbron. Het licht van de lantaarn zal gaan branden. Zodra de lantaarn volledig is opgeladen zal het licht uitgaan. Wanneer u het licht niet aan wil hebben tijdens het opladen houdt u het licht icoon ingedrukt voor 3 seconde.

Zo stelt u het apparaat in

Zorg ervoor dat de lantaarn volledig is opgeladen voordat u deze gebruikt. Zet de speaker aan door de 'O' knop 3 seconde ingedrukt te houden. De speaker zal onder de nieuwe Bluetooth connecties op uw apparaat verschijnen als 'BRAINZ S165'. Door hierop te klikken maakt uw telefoon verbinding en is de speaker klaar voor gebruik. De speaker laat weten of uw telefoon is verbonden door middel van een geluid.

Volume

Klik kort op de + knop om de volume te verhogen. Om het volume zachter te zetten klikt u op de – knop.

Muziek pauzeren

Klik kort op de 'O' knop om de muziek te pauzeren. Herhaal dit om de muziek te hervatten.

Aan/uit zetten van de lamp

Houd het licht icoon 3 seconde ingedrukt om de lamp aan te zetten. Herhaal dit om de lamp uit te zetten.

Helderheid aanpassen

Klik 2x snel achter elkaar op het licht icoon om de helderheid van het licht aan te passen. De lantaarn heeft 3 standen.

Lantaarns aan elkaar koppelen

Indien u twee Lantaarn Speakers heeft, kunt u deze koppelen voor een nog betere geluidservaring. Schakel beide speakers in, verbind deze nog niet met bluetooth en zet ze naast elkaar. Dubbel klik bij één van de speakers op de + knop. De lampen van beide speakers gaan knipperen als de speakers met elkaar verbonden zijn. Let op dit kan een aantal seconden duren. Verbind de speaker set met bluetooth. De lampen zullen stoppen met knipperen. Zodra de speakers verbonden zijn, zullen ze verbonden blijven.

Uitzetten

Houd de aan/uit knop 3 seconde ingedrukt om de speaker uit te schakelen.

Let op:

Gebruik geen oplader met een hoger voltage dan geschikt voor dit product.